



Componi la tua anta per quantificare i traversini da ordinare
Configure your panel to calculate the cross profiles
Konfigurieren Sie Ihre Tür und berechnen Sie automatisch die Querprofile

Sliding system

DIV-1445 SYNCHRO

DIV-1485 MECH

Max

100 kg

100 kg

Soft-close

80 kg (optional)

80 kg (optional)



V-1224 OPTIONAL SOFT-CLOSE

8-10

520 min
1000 max

700 min
1 pc
970 min
2 pcs




A soffitto

Ceiling

Decke

SET 1




xme661b




Anta intelaiata "Divina"

Framed door "Divina"

Geraumte Tür "Divina"



SET 1



LB = LP + LA + 100
LA/LAF = (LP + 52) / 4
LV/LF = LA - 11



DIV-1445 SYNCHRO
TRASCINAMENTO SYNCHRO CON CINGHIA
SYNCHRO DRAGGING SYSTEM WITH TOOTHED BELT
SYNCHRO MITNEHMER KIT MIT ZAHNRIEMEN



DIV-1485 MECH.
TRASCINAMENTO MECANICO
MECHANICAL DRAGGING SYSTEM
MIT MECHANISCHEM MITNEHMER



È obbligatorio rispettare la lunghezza del binario come indicato nella formula per allineare i pannelli.
It is mandatory to calculate the length of the track as in the formula for aligning the panels.
Zum Ausrichten der Paneele ist unbedingt erforderlich, die in der Formel angegebene Länge der Schiene einzuhalten.